



Packaging content

- (1) 4ZA Quick body x 2
- (2) 4ZA Quick slider x 2
- (3) End cap for cable outer x 4
- Cable crimp for inner wire x 4



Suggested tools for easy assembly:
Cable cutter, awl, allen key, marker

OPEN



CLOSED



The 4ZA Quick allows you to open your brakes during riding while keeping your hands on top of the handlebar. It works with caliper- & cantilever brakes. The cable routing and shape of the handlebar will define where the Quick is assembled. Different handlebars might result to different positioning methods. The 4ZA Quick is made of two pieces.

STEP1

Since the 4ZA Quick functions as a wedge, the outer cable (4) must be cut into 2 pieces.

Use a marker to indicate where the 4ZA Quick will be located. Choose a location making it easy to operate the 4ZA Quick so that you can reach it with your hands on the handlebar. Release the clamping mechanism, on the brake caliper, for inner brake wire.

Remove the inner brake wire and cut the brake cable outer (4) at the mark of your indication. An awl is convenient for opening the ends of cut housing.

Finish this step off by assembling the proper end caps (3) for brake cable outer afterwards.

STEP2

The correct assembly of part 2 is crucial. Assemble by sliding part 2 into part 1, in the closed position. (See drawing).

STEP3

Assemble the inner brake wire with the upper brake cable outer mounted into part 1. Slide the lower cable outer (4) onto the wire so it fits well into the lower part of part 1.

STEP4

Fix the brake cable on the brake according to the instructions of your brake

Carefully follow the assembling instructions. For further questions we advise you to contact your local 4ZA dealer. A more extended manual can be downloaded from: <http://4za.com/support-a-downloads>